

6. Drawer Assembly – Put Sides (b) into Drawer Front (a), align and confirm that all is flush. Insert and slide Drawer Bottom (c) into the grooves of Drawer Sides (b), position Drawer Back (d).
7. Slide right and left Drawer Slides (K) into Drawer Slide Holders. Position left Drawer Slide Assembly and fasten with small screws, first into pre-drilled hole on Faceframe (A), then slide Holder back flush with rear of cabinet and align with holes (3). Repeat these steps for the right side, and then mount drawer.
8. In order to mount the Large (F) and Small (G) Face Boards the Blind Corner Base should be placed in the corner and locked precisely in relation to the Large (F) and Small (G) Face Boards spotting to pre-drilled holes with the small screws provided. Place the Large Face Board (F) on the cabinet and position for the best possible fit and appearance. Mark location and secure with small screws provided. Repeat this process with Small Face Board (G).
9. After mounting the cabinet to the wall insert the Shelf Holders from the Hardware Bag (L) into the holes in the cabinet at the desired height and slide in the Shelf (C).

Your Blind Corner Base Cabinet is Complete!

