

5. To attach Large Face Board (F) to Faceframe (A) align holes in the brackets on (F) with the pre-drilled holes in the Faceframe (A) and secure with 4 small black screws.  
 Filler (G) is an optional filler that can be used if required to gap adjoining cabinet. Measure and attach.
6. After mounting the cabinet to the wall insert Shelf Holders from the Hardware Bag (H) into the holes in the cabinet at the desired height and slide in the Shelves (I).

Your Blind Corner Wall Cabinet is Complete!

