

## How to Assemble a Diagonal Corner Wall Cabinet

Before you start to assemble your cabinet, please make sure that all of the following parts are included in the carton. In case of any shortage, please contact the dealer and request the delivery of the missing part.

**A** – Door Faceframe (1)

**B** – Front Side Panels (2)

**B1** – Rear Side Panels (2)

**C** – Bottom (1)

**D** – Top (1)

**E** – Back Panel (1)

**G** – Shelves (2)

**F** – Hardware Pack (1); Shelf Holders – 8, Small Silver Screw – 12, Large Black Screw – 12

Please use the following steps to begin assembly:

1. Take out all of the parts from the carton and carefully lay the Door Faceframe (A) with finished side downwards onto a soft and flat surface so that it will not be scratched.
2. Two side panels are to be inserted into the grooves on Faceframe (A). Align the metal connectors and press downward on the half sections of the metal connectors on the Door Faceframe (A) until they fit properly into their mates on the Side Panels (B). For best results, place a screw into the metal sliders after they're locked in place.
3. Insert Top (D) and Bottom (C) into the grooves of Side Panels (B) and Faceframe (A).
4. Position Rear Side Panels (B1) so that the panel connectors align to Top Panel (D), Bottom Panel (C) and Side Panels (B). Be careful when inserting panels into position. Confirm that all is flush.
5. Slide Back Panel (E) into the grooves of the rear Side Panels (B1). Level it with the Top Panel (D) and Bottom Panel (C) and fasten it with 4 small screws into top and bottom panels. (There is no pre drilled hole for screws.)