

6. Drawer Assembly – Position Sides (b) into Drawer Front (a), align and confirm that all is flush. Insert and slide Drawer Bottom (c) into grooves of Drawer Sides (b), position Drawer Back (d) and confirm that all is flush. Secure Bottom (c) to Back(d). Repeat this step to assemble additional drawers.
7. Attach the 4 plastic Corner Braces in each corner of the cabinet using 6 of the small screws. The 4 largest screws are for use later to tie the countertop to the base through the four corner braces.

Your Drawer Base Cabinet is Complete!

